



**OFF-GRID HIRE**

Stay Powered. Stay Connected.

# QUICK START GUIDE

[www.offgridhire.com.au](http://www.offgridhire.com.au)

## GME MT610G Personal Locator Beacon

Follow these 5 easy steps to set up and use your GME Personal Locator Beacon

1

### Know What It's For

- Use only in life-threatening emergencies — it alerts international search and rescue authorities
- Transmits your GPS location and a homing signal to guide responders

2

### Already Registered – You're Good to Go

- This PLB is registered to Off-Grid Hire and is ready for use
- If activated, rescue teams will contact us — we'll pass on your details
- Treat the PLB seriously — it triggers an immediate emergency response

3

### Test Before Use

- This PLB is pre-tested but you can test it (inside first 5 minutes of any hour)
- Open the antenna and briefly press the T (Test) button
- A short strobe + green flash = working correctly

4

### Activate in an Emergency

- Raise the antenna to vertical
- Press and hold the ON button for 2 seconds (above water level)
- Flashing red LED and strobe = beacon is active and transmitting

5

### Do's & Don'ts

- Use with a clear view of the sky for best GPS signal
- Don't use indoors, underwater, or beneath metal roofs
- Call 1800 641 792 immediately if activated by mistake — no penalty applies

### More Information

View the full manual at [offgridhire.com.au/support](http://offgridhire.com.au/support) or scan the QR code on the device.