



Follow these 5 easy steps to set up and use your portable generator

1

### Before You Begin

- Use only outdoors on stable ground — never indoors or enclosed spaces
- Operate unit with at least 1 metre clearance on all sides
- Check fuel level (unleaded petrol, 91 RON or higher)
- Ensure the fuel filler cap vent is OFF before moving

2

### Set Up & Start the Generator

- Turn fuel filler cap vent ON & set Eco Throttle OFF (for faster warm-up)
- Move choke to CLOSED (if engine is cold) and turn engine switch ON
- Gently pull starter until resistance, then pull briskly
- After warm-up, return choke to OPEN

3

### Connect Your Equipment







- Wait for green “Output” light before plugging anything in
- Use only grounded (3-prong) appliances or double-insulated tools
- Switch Eco Throttle to ON for light/variable loads
- Turn devices ON one at a time, starting with the highest-power item

4

### Shutting down the Generator

- Turn off and unplug all appliances first
- Switch Eco Throttle OFF then turn engine switch to OFF
- Set fuel vent to OFF
- Allow unit to cool down before storing or transporting

### Troubleshooting Tips

-  No power output? Check that the green “Output” light is on. If not, restart generator.
-  Red overload light on? Generator is overloaded. Turn off, reduce device load, & restart.
-  Appliance won't start? Try turning Eco Throttle OFF temporarily and let generator warm up.
-  Generator shuts off during use? Check fuel level and that the fuel cap vent is still open.
-  Generator won't start? Make sure engine switch is ON, fuel in tank, & choke CLOSED (if cold).
-  Running loud/rough? Could be a heavy load. Switch Eco Throttle OFF, reduce load, & restart.

### More Information

View the full manual at [offgridhire.com.au/support](http://offgridhire.com.au/support) or scan the QR code on the device.